

Babel Drum Page 1 of 3



Instrument Components:




M8x25mm Pin Torx

Metric Conversion: 200mm/8" 400mm/16" 530mm/20 55/64" 680mm/26 49/64" 700mm/27 9/16" 850mm/33 15/32" 980mm/38 37/64" 1.5m/59"



### Installation Instructions






Weight of heaviest part 17.5kg (Large Babel Drum) Weight of heaviest part 13.4kg (Small Babel Drum)

- **1**. Unpack ground fixing legs 3no.
- **2.** Lay packaging out on floor or assemble on non-abrasive surface to prevent marking of polished stainless steel.
- 3. Align holes on legs (opposite end to polished domes) and secure in place using 3no. M10 x 200mm threaded bar and 6no. M10 nuts provided Tools required 2no. 17mm metric spanner/wrench (11/16 inch or alternatively using adjustable wrench)
- **4.** Invert assembled frame so domed ends face upwards.
- 5. Place 8mm Hex Key supplied into hole in leg and lock into internal bolt.
- 6. Remove Black caps opposite side of leg and keeping Hex Key in place, slide black polyurethane damper over bolt until flush with end of bolt. Repeat for other 2 legs
- 7. Unpack babel drum leaving black film in place to protect.


- **8**. Align holes in side of babel drum with bolts on legs.
- **9.** Using 8mm Hex Key screw bolts into drum to secure in place.
  Use thread locking solution

Use thread locking solution All hole locations are laser cut for accuracy to ensure holes in drum align perfectly with legs.



**10**. Using TX40 driver provided secure M8 x 25mm security bolts into external holes in legs 3no. Use thread lock solution

CAUTION: Drum surface can get hot in direct sunlight, if possible install in shaded areas.





Ground Fix Components:





Spares available from percussionplay.com or from your local distributor



Babel Drum Page 2 of 3




Instrument Components:





M8x25mm Pin Torx


Thread Lock Solution Required





















Babel Drum Page 3 of 3



#### Components:



M10x200 Threaded Bar



M10 BZP Nut

Metric Conversion: 50mm/2"

250mm/10"

350mm/14"


400mm/16"

450mm/18"




# Ground Fix Installation


1 Insert M10x 200 Threaded bar into pre drilled holes in Frame of Babel Drum using M10 BZP Nuts




Excavate a holes with a 250mm diameter tapering down to 350mm diameter and 450mm depth





Compact base of hole with 50mm of aggregate. Lower ground Fix post attached to instrument into hole (check instrument straight and level before filling with concrete)



4 Fill hole with fast drying concrete to manufacturers specifications.







Foundations should not present a hazard. These foundations are recommended as a guide, for more information on foundation details for various surface see Part 7 of BS EN 1176.



Rainbow Sambas Page 1 of 4



Instrument Components:


Rainbow Sambas are preassembled

Metric Conversion: 80mm/3" 100mm/4" 230mm/9" 300mm/12" 400mm/16" 450mm/18" 1.5m/59"



# Installation Instructions





3. Excavate marked holes to 300mm depth making sure the holes have a level base allow the sambas to sit vertical.

4. Once happy with location of the sambas, fill holes using rapid hardening concrete. Be sure to compact concrete around metal brackets and leave to dry according to manufactures guidelines.

1. Assemble fixing brackets to base of sambas using M8x25mm security screws and lock washers. (1.1)(See Assembly Guide)

2.Arrange Sambas with

minimum spacing between


each drum at 230mm and

mark holes for excavation.


100mm larger than the drum

Each hole should be 80-

itself.



Sambas will arrive on site in pre set heights. In ground fixing depth 300mm for all 5 sambas.



Weight of heaviest part 14.6kg (XL Samba)



Ground Fix Components:









Rainbow Sambas Page 2 of 4




Instrument Components:

Rainbow Sambas are preassembled

Thread Lock Solution Required (Not Supplied)



# Assembly Guide PPRASA








Tools:

TX 40 Driver Bit



PPRASA FRONT



Ground Fix Components:









Rainbow Sambas Page 3 of 4



#### Components:






M8 Lock Washer

x17

L Brackets







Rainbow Sambas Page 4 of 4



#### Components:



M8x25mm Pin Torx



L Brackets x17

Metric Conversion:

65mm/3"

250mm/8"

250mm/8" 300mm/12"

350mm/14"

415mm/ 16"

415mm/ 16 450mm/ 18"


500mm/20"


515mm/20"


600mm/24"




# Ground Fix Installation










Foundations should not present a hazard. These foundations are recommended as a guide, for more information on foundation details for various surface see Part 7 of BS EN 1176.





Tubular Bells Page 1 of 2



Instrument Components:


Tubular Bells are preassembled

Metric Conversion: 250mm/10" 400mm/16" 600mm/24" 1.5m/59" 2207mm/98"



# Installation Instructions






Weight of heaviest part 10kg (XXL Bell)


1. Using M10 nuts and 150mm bolts supplied locate through pre drilled holes and secure bolts in place to support in ground pole in concrete. 2 bolts per leg at 90 degree angles

2.Excavate 7 holes for Tubular Bells 250mm diameter by 600mm deep. 2 further holes will be needed for the beater poles according to layout of Bells at 250mm diameter and 400mm deep.

3. Locate (lower) legs into holes making sure they are vertical and level prior to concreting in place

4. Once happy with location of the Tubular Bells, fill holes using rapid hardening concrete. Be sure to compact concrete around legs and leave to dry according to manufactures guidelines







Ground Fix Components:







Tubular Bells Page 2 of 2



#### Components:



M10x200 Threaded Bar



x28

M10 BZP Nut

Metric Conversion: 50mm/2"

50mm/ 2

250mm/10" 350mm/14"

400mm/16"

450mm/18"


600mm/24"

60011111/24

650mm/26"



# Ground Fix Post Installation




Insert M10x 150 Threaded bar into pre drilled holes in Ground Fixing Post



3

Fix M10x 150 Threaded bar in place using M10 Nuts



Excavate 7 holes with a 250mm diameter tapering down to 350mm diameter and 650mm depth

