

# Installation Instructions

**1. Position Freechimes** in desired location, according to correct Key stage height, this may require 2 persons.




**2. Mark hole locations** for each of the brackets at correct spacing in desired location

**3. Drill hole locations** according to your chosen fixings (frame fixings, wall bolts or chemical anchors) depending of the structure of the wall.

**4. Fix through Brackets to surface** with suitable fixings (not supplied) in correct orientation and Key stage and attached notes with fixings provided.

**5. Beaters** can be fixed to Backboards or directly to wall depending on customers preference.

Install Instrument with 1m free space (from widest point) around it.



Wall Fixed Freechimes Notes Only Alto/ Soprano



Components:




M6 Saddle Straps X2



10x38mm Secure Screw X4

PLAN VIEW



FREC Bracket  
Pentatonic X12  
Diatonic X16



M6 Form C Washer  
Pentatonic X24  
Diatonic X32



RUBBER WASHER  
Pentatonic X24  
Diatonic X32



RUBBER GROMMET  
Pentatonic X24  
Diatonic X32



M6x 30 PIN TORX  
Pentatonic X24  
Diatonic X32



Pair Small/Large Beaters X1

Wall fixings are not supplied, installer will select suitable method of fixing.



Spares available form [percussionplay.com](http://percussionplay.com) or from your local distributor

9-15 Kg