

Surface Fixed Calypso Chimes Page 1 of 4



Instrument Components:



M6x20 Security Screw



x2

M6 Saddle Strap



M6 Square Nut



Beater Holder

Metric Conversion: 1510mm/59" 1.5m/59"



Installation Instructions









Weight of heaviest part 7.5kg

- 1. Instrument will arrive on site fully assembled. (1.1) (See Assembly Guide)
- 2. Attach Surface Fixing posts to legs. (1.2) (See Surface Fix Post Installation Sheet)



- 4. Fix to Surface using recommended ground anchors not supplied.
- 5. Make sure all fixings are covered and secure using cover caps provided.
- **6**. Attach the holder, beater and the saddle strap on side of the post. (1.3)

















Surface Fixed

Calypso Chimes Page 2 of 4



Instrument Components:

x4 M6x20 Security Screw

√ x1

M6 Saddle Strap



M6 Square Nut



×1

Beater Holder


Thread Lock Solution Required (Not Supplied)



Assembly Guide PPCALQU








COMPONENTS LIST:

2 Part Cover Cap X4



M10x70 Pin torx X1

™ M6 Square Nut X2

Beater Holder X1



Surface Fix Components:









Surface Fixed Calypso Chimes Page 3 of 4



Instrument Components:



M6 Saddle Strap



x2 M6 Square Nut




Beater Holder


600mm min spacing

Thread Lock Solution Required (Not Supplied)



Assembly Guide PPCALQU







Surface Fix Components:









Surface Fixed Calypso Chimes Page 4 of 4



Components:




M10 Barrel Nut




M10x70 Security Screw

Thread Lock Solution
Required (Not Supplied)


Surface Fix Post Installation



Locate the Surface fix Plate into the leg of the instrument.



Fix instrument to Surface fix plate using M10 bolt and Barrel Nut and use **thread locking solution** to prevent fixings working loose.



Fix Surface Plate to the ground surface **Ground Anchors Not provided**cover fixings with caps provided



