



# Installation Instructions

In ground fixing always 600mm for each chime and 400mm for beater poles



**Ground Fixed**  
Colossus Chimes  
Page 1 of 2





**1.** Attach Ground Fixing posts to legs. (1.2) (See Ground Fix Post Installation Sheet)

**2.** Excavate 11 holes for Emperor chimes 250mm diameter by 600mm deep in desired location upon decision from customer. 4 further holes will be needed for the beater poles according to layout of chimes at 250mm diameter and 400mm deep.

**3.** Locate (lower) legs into holes making sure they are vertical and level prior to concreting in place. Chimes fixings should be 50mm from ground surface.

**4.** Once happy with location of the chimes, fill holes using rapid hardening concrete. Be sure to compact concrete around legs and leave to dry according to manufactures guidelines.



Weight of heaviest part 9kg (Chime)

Instrument Components:

Colossus Chimes are pre-assembled

Metric Conversion:  
100mm/ 4"  
250mm/ 10"  
600mm/ 24"  
1.5m/ 59"  
1565mm/ 62"  
2352mm/ 93"



Large Red Beaters X4

Ground Fix Components:

x22  
M10x200 Threaded Bar

x44  
M10 Nut

x11  
M10x50 Security Screw

x11  
M10 Barrel Nut



Spares available from [percussionplay.com](http://percussionplay.com) or from your local distributor

**130 Kg**


# Ground Fix Post Installation

Foundations should not present a hazard. These foundations are recommended as a guide, for more information on foundation details for various surface see Part 1 of BS EN 1176.


Tools:  
 x2  
 TX 45 Driver Bit

Metric Conversion:  
 50mm/ 2"  
 100mm/ 4"  
 250mm/ 10"  
 350mm/ 14"  
 600mm/ 24"  
 650mm/ 26"


Ground Fixed  
 Colossus Chimes  
 Page 2 of 2



1 Insert M10x 150 Threaded bar into pre drilled holes in Ground Fixing Post




2 Fix M10x 150 Threaded bar in place using M10 Nuts




3 Locate the Ground fix Post into the leg of the instrument.

Thread Lock Solution Required (Not Supplied)




4 Fix instrument to Ground fix post using M10 bolt and Barrel Nut and use **thread locking solution** to prevent fixings working loose.




5 Excavate 11 holes with a 250mm diameter tapering down to 350mm diameter and 650mm depth


600mm max depth



6 Compact base of hole with 50mm of aggregate. Lower ground Fix post attached to instrument straight and level before filling with concrete)



7 Fix hole with fast drying concrete to manufacturers specifications.



Components:

- x22
- x44
- x11
- x11

Thread Lock Solution Required (Not Supplied)