



Installation Instructions

1. Attach Surface Fixing plates to the base of each chime. (1.1)
(See Surface Fix Plate Installation Sheet)




Install Instrument with 1.5m free space (from widest point) around it.

2. Locate Chimes to desired location and mark holes to fix to desired surface.





Surface fixing centre spacing 600mm for each chime and 300mm for beater poles

3. Fix to Surface using recommended ground anchors not supplied.



4. Make sure all fixings are covered and secure using cover caps provided

Weight of heaviest part 9kg (Chime)



(1.1)

Beater Pole

Surface Fixed
Colossus Chimes
Page 1 of 2



Instrument Components:

Colossus Chimes are pre-assembled

Metric Conversion:
100mm/ 4"
250mm/ 10"
600mm/ 24"
1.5m/ 59"
1565mm/ 62"
2352mm/ 93"



Large Red Beaters X4

Surface Fix Components:

x15
M10x50 Security Screw

x15
M10 Barrel Nut

x60
2 Part Cover Cap



Spares available from percussionplay.com or from your local distributor

130 Kg

Ground Fix Post Installation


Tools:

 x2
TX 45 Driver Bit

Surface Fixed
Colossus Chimes
Page 2 of 2




Components:

 x15
M10 Barrel Nut


 x15
M10x50 Security Screw

 x60
2 Part Cover Cap


Thread Lock Solution
Required (Not Supplied)



1
Locate the Surface fix Plate into the leg of the instrument.



2
Fix instrument to Surface fix plate using M10 bolt and Barrel Nut and use **thread locking solution** to prevent fixings working loose.



3
Fix Surface Plate to the ground surface **Ground Anchors Not provided** cover fixings with caps provided

Repeat Parts 1-3 for all 11 chimes an 2 beater poles

