



Installation Instructions

1. Attach Surface Fixing plates to the base of each chime (1.1) (See Surface Fix Plate Installation Sheet)




Install Instrument with 1.5m free space (from widest point) around it.

2. Locate Chimes to desired location and mark holes to fix to desired surface.



Surface fixing centre spacing 600mm for each chime and 300mm for beater poles


3. Fix to Surface using recommended ground anchors not supplied




Beater Pole

(1.1)

Beater Pole



4. Make sure all fixings are covered and secure using cover caps provided



Weight of heaviest part 9kg (Chime)



Played with hands

Surface Fix Components:

x15
M10x50 Security Screw

x15
M10 Barrel Nut

x60
2 Part Cover Cap

Spares available from percussionplay.com or from your local distributor

130 Kg

Surface Fixed
Colossus Chimes
Page 1 of 2



Instrument Components:

Colossus Chimes are pre-assembled


Metric Conversion:
100mm/ 4"
250mm/ 10"
600mm/ 24"
1.5m/ 59"
1565mm/ 62"
2352mm/ 93"

Ground Fix Post Installation

Tools:

 x2
TX 45 Driver Bit

Surface Fixed
Colossus Chimes
Page 2 of 2



Components:



x15



x15

M10x50 Security Screw




x60

2 Part Cover Cap


Thread Lock Solution
Required (Not Supplied)

1




Locate the Surface fix Plate into the leg of the instrument.

2



Fix instrument to Surface fix plate using M10 bolt and Barrel Nut and use **thread locking solution** to prevent fixings working loose.

3



Fix Surface Plate to the ground surface **Ground Anchors Not provided** cover fixings with caps provided

Repeat Parts 1-3 for all 11 chimes an 2 beater poles